


## **Drilling Fluid Programs Guide**

NZ Freephone 0800 646 372 AU Freephone 1800 309 734 sales@industrial-minerals.co.nz

## **HDD Recommended Mud Mixes**



If viscosity is required, use Liquid Polymers.

For increased gel strength to transport cuttings, use Xanthum Gum in place of a liquid polymer. Water treatment: Soda Ash is recommended as it will not increase the PH, but will treat the water and improve performance.

Bentonite Pallets: BG 10, Quartz filter Gravels: Q sands, Foams: Ultra foam

C:Filingcab/drilling fluid programs